



No Hose or Cable Wrap-up Regardless of Direction of Rotation.
Oxy-Fuel, Plasma Cutting and Welding Units Available.

Bug-O Systems is guided by honesty, integrity and ethics in service to our customers and in all we do.

BUG-O SYSTEMS

A DIVISION OF WELD TOOLING CORPORATION

CE

280 TECHNOLOGY DRIVE CANONSBURG, PENNSYLVANIA 15317-9564 USA PHONE: 412-331-1776 http://www.bugo.com FAX: 412-331-0383



# **Bug-O Makes The ...**

Wire reel adaptor for 30 lb. (13.6 kg) spools on the CW-5. 60 lb. (27 kg) wire reels included on the CW-7, CW-11 and CW-18.

Strong permanent magnet motor and gear train insure smooth movement of the welding torch.

For sub-arc applications, a 25 lb. (11 kg) capacity flux hopper is included on the CW-5AX, CW-7, CW-11 and CW-18. \*Flux Recover Available


Rise and fall cam, raises and lowers the torch to follow the contour of the pipe or vessel.


Welding gun and cable assembly included.

Racking groups for horizontal and vertical adjustment of the welding gun. Motorized racking is available.

Torch angle adjuster (optional on CW-5) standard on all other machines.


Electric oscillators are available








## **Circle Welders**



The CW-5 Circle Welder (CWO-1500) is designed for single or multi-pass welding of couplings or nozzles on pipe and vessels utilizing MIG or Flux Core process, with gas shield. The machine is equipped with its own wire feeder, rotation drive motor, rise and fall cam assembly and welding gun. Horizontal and vertical racking to position the torch and a 30 lb (14 kg) spool holder. For more detailed info. please see our "CW-5" tech sheet online at bugo.com

The CW-5 with Remote Control (CWE-1500) has a digital readout for rotation speed. It also has controls for: wire feed speed, cold inch/purge, pre-flow and post-flow, burn back and wire feeder forward and reverse. Overlap is also adjustable. This control has both manual and automatic settings. In the manual setting, you can check all your controls and travel speed to make sure the machine is functioning properly. In the automatic setting, with one push of a button, the unit will start the weld process, weld completely around the workpiece, overlap the end of the weld, turn the weld off and return to the start position. It is ready for the next weld. The CW-5 is supplied with the following cables: 50" (15.2 m) of gas hose, 50" (15.2 m) hot lead, 50" (15.2 m) control cable and all cables from the remote box to the circle welder. For more detailed info. please see "CWE-1500" tech sheet online at bugo.com



The **CW-5AX Circle Welder (CWO-1560)** is designed for single pass or multi pass welding of couplings and nozzles on pipe and vessels. The unit is available for Sub Arc, MIG or Flux Cored process.

The CW-5AX offers all the same features as the CW-5 as well as a meter kit, torch angle adjuster and flux hopper. For more detailed info. please see our "CW-5AX" tech sheet online at **bugo.com** 


The CW-7 Circle Welder (CWO-1700) is equipped for MIG, Flux Core or Sub Arc welding on vessels and domed heads. The CW-7 has a working range of 6"-24" (152-610 mm) O.D. nozzles with no cable wrap up for multi-pass welding. This unit is capable of using welding wire sizes from .035"-3/32" (.8-2.4 mm).


The machine is equipped as shown and will carry 60 lbs. (27 kg) spools of wire. The



unit is complete with wire feeder, gun and cable assembly, flux hopper, wire reel and meter kit. Mounts on 3-jaw chuck. (See chart on page 5 for welding capacities). For more detailed info. please see our "CW-7" tech sheet online at **bugo.com** 









The **CW-18 Circle Welder (CWO-1800)** is designed for welding of nozzles into vessels or domed heads utilizing SUB-ARC. The CW-18 mounts on a 3-Jaw Chuck welding diameter 10" to 50" (152-1270 mm) O.D. It is capable of using welding wire diameters 3/32-7/32" (2.4-5.6 mm). For more detailed info. please see our "CW-18" tech sheet online at **bugo.com** 

### **Circle Welder Capacities**

Model	Process Capabilities	Welding Diameter*	Welding Wire Size	Rotation Speeds	Rise and Fall Cam	Rating amps	Standard Equipment
<b>CW-5</b> CWO-1500	MIC/MAAC	1-12"	.035-1/16"		0-5"	300 amps	Burn back control,
CW-5 W/Remote CWO-1500	MIG/MAG, FCAW	(25- 300mm)	(.8-1.6mm)	.5-6.0 rpm	(0-25mm)	100% duty cycle	horizontal and vertical adjustment gun & cable
<b>CW-5AX</b> CWO-1560	MIG/MAG, FCAW, SAW	1-12" (25- 300mm)	.035-3/32" (.8-2.4mm)	.5-6.0 rpm	0-5" (0-25mm)	500 amps 100% duty cycle	Same as CW-5 plus: meter kit, torch angle adjuster, flux hopper, nozzle & cone.
<b>CW-7</b> CWO-1700	MIG/MAG, FCAW, SAW	6-24" (150- 600mm)	.035-3/32" (.8-2.4mm)	.2-2.2 rpm	0-7" (0-175mm)	500 amps 100% duty cycle	Burn back control, horizontal and vertical adjustment gun & cable.
<b>CW-11</b> CWO-1100	MIG/MAG, FCAW, SAW	10-50" (254- 1270mm)	Solid Wire .035-3/32" (.8-3.0mm) Flux Cored Wire .068120" (1.7-3.0mm)	.2-2.2 rpm	0-7" (0-175mm)	500 amp CO <sub>2</sub> 400 amp mixed gas- ses 60% duty cycle	Burn back control, horizontal and vertical adjustment gun & cable.
<b>CW-18</b> CWO-1800	SAW	10-50" (254- 1270mm)	Solid Wire 3/32-7/32" (2.4-5.6mm)	.2-2.2 rpm	0-7" (0-175mm)	1200 amps	Burn back control, horizontal and vertical adjustment gun & cable.

\*NOTE: Welding diameter capacities cannot exceed two thirds diameter of the workpiece.



# **Programmable Circle Welders**



The CWP-5 Programmable Circle Welder (CWP-1500) is designed for single or multi-pass welding of couplings or nozzles utilizing MIG or Flux Core process capable of welding 1-12" (25-305 mm) diameters. This machine uses a microprocessor to control the rise and fall through encoder position.

The CWP-5AX Programmable Circle Welder (CWP-1560) is designed for single or multi-pass welding of couplings or nozzles utilizing Sub-Arc, MIG or Flux Core process capable of welding 1-12" (25-305 mm) diameters. This machine uses a microprocessor to control the rise and fall through encoder position.

The CWP-7 Programmable Circle Welder (CWP-1700) is equipped for MIG, Flux Core or Sub-Arc welding on vessels and domed heads. The CW-7 has a working range of 6-24" (152-610 mm) O.D. nozzles with no cable wrap up for multi-pass welding. This machine uses a microprocessor to control the rise and fall through encoder position.

These units are capable of using welding wire sizes from .035-3/32" (.8-2.4 mm). Please refer to the chart (on pg. 7) for additional information.



The CWP-18 Programmable Circle Welder (CWP-1800-SA) is designed for single or multi-pass welding of couplings or nozzles into vessels or domed heads utilizing Sub-Arc, MIG or Flux Core process with gas shielding. The CWP-18 mounts on a 3 jaw chuck for welding diameters of 10-50" (254-1270 mm) O.D. This machine uses a microprocessor to control the rise and fall through encoder positioning. Photo shown with optional Flux Recovery System installed.




The CWP-11 Programmable Circle Welder (CWP-1100) is designed for welding of nozzles into vessels utilizing Sub-Arc, MIG or Flux Cored Process. The CWP-11 mounts on a 3-Jaw Chuck for welding diameter 6-50" (152-1270 mm) O.D. The machine uses a microprocessor to control the rise and fall through encoder positioning. Photo shown with optional Flux Recovery System installed.



# **Programmable Circle Welders**

Model	Process Capabilities	Welding Diameter	Welding Wire Size	Rotation Speeds	Rise / Fall	Rating amps	Standard Equipment
<b>CWP-5</b> CWP-1500	MIG/MAG, FCAW	1-12" (25- 305mm)	.035-1/16" (.8-1.6mm)	.5-6.0 rpm	CNC Controlled	300 amps 100% duty cycle	Burn back control, horizontal and vertical adjustment gun & cable
CWP-5AX CWP-1560	MIG/MAG, FCAW, SAW	1-12" (25- 305mm)	.035-3/32" (.8-2.4mm)	.5-6.0 rpm	CNC Controlled	500 amps 100% duty cycle	Same as CW-5 plus: meter kit, torch angle adjuster, flux hopper, nozzle & cone.
<b>CWP-7</b> CWP-1700	MIG/MAG, FCAW, SAW	6-24" (150- 610mm)	.035-3/32" (.8-2.4mm)	.2-2.2 rpm	CNC Controlled	500 amps 100% duty cycle	Burn back control, horizontal and vertical adjustment gun & cable.
<b>CWP-11</b> CWP-1100	MIG/MAG, FCAW, SAW	10-50" (254- 1270mm)	Solid Wire .035-3/32" (.8-3.0mm) Flux Cored Wire .068120" (1.7-3.0mm)	.2-2.2 rpm	CNC Controlled	500 amp CO <sub>2</sub> 400 amp mixed gasses 60% duty cycle	Burn back control, horizontal and vertical adjustment gun & cable.
<b>CWP-18</b> CWP-1800	SAW	10-50" (254- 1270mm)	Solid Wire 3/32-7/32" (2.4-5.6mm)	.2-2.2 rpm	CNC Controlled	1200 amps	Burn back control, horizontal and vertical adjustment gun & cable.


### **Capabilities**






### **Circle Welders**

### **Accessories**




#### **CWO-1645 Torch Weaver**

Provides a pendulum-type motion to the gun for weave welding. The speed and stroke of oscillation are adjustable.




#### **CWO-3023-1 Torch Angle Adjuster**

Allows the operator to adjust the angle of the gun precisely, without unclamping the holding devise.



#### CWO-5790 Cone Adaptor

A tapered centering devise used to center the machine on nozzles. The range of the Cone Adaptor is 1-1/4" to 4" (32-102 mm) diameter.



### **CWO-3670 Step Adaptor for Threaded Outlets**

A stepped centering device used to center the machine on threaded I.D. weld-o-lets. The range of the Step Adaptor is 1/2" to 4" (13-102 mm) diameter.

**CWO-3675 Step Adaptor for Grooved Outlets** 1 1/4" - 1 1/2" - 2" - 2 1/2" - 3", 4"





#### CWO-3660 Lathe Chuck

2"-10" (50-254mm) lathe chuck for small fittings and nozzles.



#### 3-Jaw Expandable Chuck


Mounts and automatically centers the Circle Welder on nozzles with or without flanges. For use with all circle welders.

PART NO.	FOR NOZZLE I.D.'s	WEIGHT	
CWO-3660	2"-10" (50-254 mm)	69 lbs. (31.3 kgs)	
CWO-3661	8"-16" (204-405 mm)	36 lbs. (16 kgs)	
CWO-3662	10"-24" (255-610 mm)	51 lbs. (23 kgs)	
CWO-3663	24"-42" (610-1065 mm)	64 lbs. (29 kgs)	




# **Circle Welders**

### **Carriages**




#### CWO-4530 Carriage

May be used only with CW-5 CIRCLE WELDERS. The carriage, which is mounted on a standard monorail, is used to move the welder along a length of pipe.




#### CWO-4540 Carriage

This carriage, which is mounted on a standard monorail, is used with the CB-1P AIR PLASMA MACHINE. A winch holds the machine and prevents the machine from falling into the hole when the slug drops. This carriage may also be used with CW-5 CIRCLE WELDERS.



#### **CWO-4550 Motorized Carriage**

May be used with either the CW-5 CIRCLE WELDER or the CB-1P AIR PLASMA MACHINE. Provides motorized vertical travel of the machine.



### **Submerged Arc Flux Recovery System**

CWO-2020 120 volt CWO-2025 240 volt


Continuously removes and recycles all unused flux. Available on any CW-5AX, CW-7, CW-11 and CW-18.


### Pneumatic Flux Recovery System CWO-2020-AP


Continuously removes and recycles all unused flux. Available on any CW-5AX, CW-7, CW-11 and CW-18.



# **Circle Burners**









The CB-1PR Plasma Circle Burner with Remote Control (CBP-2020) is designed for cutting beveled holes in lightwall pipe or vessels. This machine is supplied with a Thermal Dynamics air plasma power source (Hypertherm power source also available), torch and 50' (15 m) leads. The CB-1PR must be mounted on a carriage or fixture.

Thermal Dynamic	s Cutmaster 82		Hypertherm Powermax 85		
			Power Auto voltage runs on 200-600 Volts, 1 or 3-phase, without the need of rewiring.		
	20-80 Amps	Adjustable Output Current	25-85 Amps	awermax est	
THE STATE OF THE S	(Recommended) 3/4" (19 mm) Max	Cutting Capacity	(Recommended) 3/4" (19 mm) Max	P	



The CB-2 Circle Burner (CBO-2000) uses Oxy-fuel for square or beveled hole cuts (see chart for capacities). The CB-2 is mounted on a special frame with a releasable permanent magnet base. Machine includes variable speed rotation, 2-hose Oxy-fuel machine torch, adjustable tip adaptor, vertical and horizontal torch adjustment and rise and fall cam. For more detailed information please see our "CB-2" tech sheet online at bugo.com



The CB-3 Circle Burner (CBO-3000) uses Oxy-fuel for square or beveled hole cuts (see chart for capacities). Unit includes 2-hose Oxy-fuel machine torch, adjustable tip adaptor, variable speed rotation, vertical and horizontal torch adjustment and rise and fall cam. The CB-3 must be mounted on a column and boom, manipulator or fixture. For more detailed information please see our "CB-3" tech sheet online at bugo.com


### **Circle Burner Capacities**


Model	Burning Diameter*	Mounting	Process	Rise and Fall Cam	Net Weight	Use
<b>CB-2</b> CBO-2000	1.5"-42" beveled holes (38-1067 mm) 4"-48" square cut (102-1219 mm)	Manually Operated Magnet	Oxy-fuel	0-7" (0-178 mm)	225 lbs. (102 kg)	vessels, large diameter pipe
<b>CB-3</b> CBO-3000	1.5"-42" beveled holes (38-1067 mm) 4"-48" square cut (102-1219 mm)	Carriage or Manipulator	Oxy-fuel	0-7" (0-178 mm)	170 lbs. (77 kg)	domed heads, vessels, large
<b>CB-1P</b> CBO-1020	.5"-12" beveled holes (13-305 mm)	Carriage or Manipulator	Plasma	5" (127 mm)	170 lbs. (77 kg)	Thin wall, small diameter pipe
CB-1P W/ Remote CBP-2020	.5"-12" beveled holes (13-305 mm)	Carriage or Manipulator	Plasma	5" (127 mm)	170 lbs. (77 kg)	Thin wall, small diameter pipe

\*NOTE: Burning diameter cannot exceed two thirds diameter of the workpiece.





# **Programmable Circle Burners**





The CBP-3 Programmable Circle Burner (CBP-3000) must be mounted on a column and boom, manipulator or fixture. Uses Oxy-fuel for square or beveled hole cuts (see chart for capacities). Unit includes 2-hose oxy-fuel machine torch, adjustable tip adaptor, variable speed rotation, vertical and horizontal torch adjustment.





The CBP-4 Programmable Circle Burner (CBP-4000) is mounted on a special frame with a releasable permanent magnet base. Uses Oxy-fuel for square or beveled hole cuts (see chart for capacities). Machine includes variable speed rotation, 2-hose oxy-fuel machine torch, adjustable tip adaptor, vertical and horizontal torch adjustment.

### **Programmable Circle Burner Capacities**

Model	Burning Diameter	Mounting	Process	Rise and Fall Cam	Net Weight	Use
<b>CBP-3</b> CBP-3000	1.5"-42" beveled holes (38-1067 mm) 4"-48" square cut (102-1219 mm)	Carriage or Manipulator	Oxy-fuel	0-7" (0-178 mm)	170 lbs. (77 kg)	domed heads, vessels, large
<b>CBP-4</b> CBP-4000	1.5"-42" beveled holes (38-1067 mm) 4"-48" square cut (102-1219 mm)	Manually Operated Magnet	Oxy-fuel	0-7" (0-178 mm)	225 lbs. (102 kg)	vessels, large diameter pipe



# **Saddle and Elbow Cutters**

The MM1 Programmable Pipe Cutter (SEO-3500) is a computer controlled machine that automates the cutting of profiles, holes and shapes on pipe with diameters from 4"-16" (102-406 mm). It rotates the pipe on it's roller bed with a three jaw chuck while simultaneously moving a cutting torch back and forth along the pipe's axis. Pre-programmed shapes such as saddle, hillside, lateral and miter cuts can be made by simply selecting the type of cut from the menu, then entering the diameters of the pipes being processed and pressing the run button to cut your pipe.


\*Oxy-fuel versions are available.

\*Optional: Machine cutting capacity can be increased to 24" (610 mm) diameter at factory.

For more detailed information please see "MM1 Programmable Pipe Cutter" brochure online at bugo.com









# **Saddle and Elbow Cutters**

The SE-2PTD and SE-4PTD Programmable Pass Through machines provide dual programming capabilities. A "Pipe" program for making Saddle Cuts, Offset Cuts, Laterals and Miters. A second (selectable) program is used for cutting customized shapes in pipe. Oxy-fuel or Plasma models are available. This eliminates the need to make templates or layout complex cuts.

SE-2PTD

Oxy-fuel Version SEO-4250-OX SEO-4250-PL Plasma Version

**SE-4PTD** SEO-4400-OX Oxy-fuel Version SEO-4400-PL Plasma Version

**NOTE:** SEO series machines do not include torch or plasma machine.

For more detailed information please see "SE-4PD, SE-2PTD & SE-4PTD" brochure online at bugo.com

**SEO-4400-3 AXIS** 

SE-4PTD with third axis option as shown on left.


An additional third axis-torch rotation is available. The programmed torch rotation only works with cuts: 1, 2, 4 and 5 (see page 15).

The SE-4PD Programmable Saddle and Elbow Cutter is a programmable machine. It will cut saddles, laterals, miters, offsets (hillsides) and elbows using a micro-processor and handheld terminal. Oxy-fuel or Plasma models are available. Cutting diameter 1"-12" (25-300 mm). (Maximum length of pipe to be cut, 18" [450 mm]).

The maximum rotation speed is 3.7 rpm, which is 47 ipm (1160 mm/min) on 4" (102 mm) O.D.'s.

SEO-4520-OX Oxy-fuel Version SEO-4520-PL Plasma Version

For more detailed information please see "SE-4PD. SE-2PTD & SE-4PTD" brochure online at bugo.com




SADDLE AND ELBOW CUTTER CAPACITIES	Model	Process Through	Pass	Pipe Diameter Range	Speed Rotation	Range of Pipe Lengths that can be Cut
	SE-2PTD	Plasma or Oxy-fuel	1" - 4" (25 - 102 mm)	1" - 14" (25 - 356 mm)	.3 3.7 rpm	3"-18" (76 - 457 mm)
	SE-4PD Plasma or Oxy-fuel N/A 1" - 12" (25 - 305 mm)		· · · · ·	.3 3.7 rpm	3"-18" (76 - 457 mm)	
	SE-4PTD	Plasma or Oxy-fuel	4" - 12 3/4" (102 - 324 mm)	4" - 20" (102 - 508 mm)	.2 3 rpm	3"-20" (76 - 508 mm)
	MM1	Plasma or Oxy-fuel	N/A	Standard Machine 4"-16" (102 - 406 mm) Optional 4"-24" (102 - 610 mm)	.2 3 rpm	3"-38 ft. (76 mm - 11.6 m)




# **Saddle and Elbow Cutters**

### **Capabilities**



#### **Hand Held Terminal:**



### **Example: Programming Sequence for Type 3 Cut.**

- Press the reset button on the machine. The hand held terminal will display "READY".
- 2. Press "A" on the terminal. The terminal will ask you what type of cut you want. (See Types 1-5).
- 3. Press the number desired and then press "ENTER".
- **4.** The terminal will ask for the diameter of the small pipe. Press the appropriate dimensions and press "ENTER".
- The terminal will ask for the diameter of the large pipe. Press the appropriate dimensions and press "ENTER".
- 6. Enter the offset dimension.
- 7. Enter the "ANGLE" in degrees.
- **8.** Press "START" on the machine to begin the cut. It couldn't be easier!


When using Plasma, press "B" and enter the time delay required (which is stored until changed again).



# **Sprinkler Fabrication Equipment**



#### TYPICAL SET UP FOR SPRINKLER FABRICATION



#### Sequence of Operation

Position your pipe and move the CB-1P along the pipe to cut The approximate time for a cut is 6-10 seconds, depending smooth, accurate holes. Position the CW-5 with a step adapter upon diameter and thickness. The approximate time for a on the fitting and make the contour weld.

weld is 15-20 seconds.